


# TempTrac™




**BOILER & WATER HEATER  
ELECTRONIC CONTROLLER**

## **USER MANUAL**




# 1. DISPLAY AND INTERFACE


## 1.1 KEYBOARD BUTTONS

- 


**SET**

  - Displays and modifies the temperature set points.
  - In programming mode, it selects a parameter or confirms an operation.
- 


**UP**

  - Displays and modifies the energy saving (Night Time setback) settings.
  - In programming mode, it browses the parameter codes or increases a displayed value.
- 


**DOWN**

  - Displays the working hours of the load relays.
  - In programming mode, it browses the parameter codes or decreases a displayed value.
- 

**CLOCK**

  - Changes lower display from inlet temperature to current time and day.
- 


**EXT**


  - Changes upper display from Outlet Temperature to Outdoor Reset temperature probe reading and displays the temperature difference of the Inlet Temperature minus Outlet temperature.
  - In programming mode it sets the 4-20mA output (password is required).
- 


**ON/OFF**

  - Switches the control ON or OFF.

## 1.2 KEY COMBINATIONS

















- 

To lock and unlock the keyboard.
- 

To enter the programming mode.
- 


To exit the programming mode.


## 1.3 LED ICON LEGEND


LED	MODE	Function
°F	ON	Temperatures are displayed in Fahrenheit degree
°C	ON	Temperatures are displayed in Celsius degree
	Flashing	Call for heat time delay
	ON	Call for heat is on
	Flashing	Second stage time delay (On 2-stage units only)
	ON	Second stage on
	Flashing	Freeze protection time delay
	ON	Freeze protection on
	ON	Modulation output signal is in manual control mode
	ON	Modulation output signal is automatically controlled by temperature probe 1
<b>Ext</b>	ON	The outside temperature is displayed
	FLASHING	Low gas pressure alarm
	FLASHING	High gas pressure alarm
 	FLASHING	Low-water alarm
	ON	Lower LED readout is displaying the clock
	FLASHING	Alarm signal
	FLASHING	Programmed working hours limit is exceeded
	ON	Working hours are displayed in Lower LED readout
ES	ON	The energy saving function is running

## 1.4 UPPER LED READOUT

The default display of this readout is the temperature sensed at the outlet of the PRIMERA (Probe 2)


By pressing and releasing the  button once, the Upper LED will display the actual temperature sensed at Probe 3 (Optional Outdoor Temperature Reset Thermostat).

By pressing and releasing the  button twice, the Upper LED will display the difference between the actual outlet temperature sensed at Probe 2 and the returning inlet temperature (Probe 1) to the PRIMERA.



To return to the default in the Upper LED readout, wait 15 seconds after the  button is pressed and released twice.



## 1.5 LOWER LED READOUT

The default display of this readout is the temperature sensed at the inlet of the PRIMERA (Probe 1). In a Boiler, Probe 1 will be inserted into the return piping of the boiler heating loop. In a Water Heater, Probe 1 will be inserted into the side arm storage tank.


By pressing and releasing the  button once, the Lower LED display will show the Time of Day. Press again to return to default display.



## 1.6 TO SET THE CURRENT TIME AND DAY (MILITARY TIME)

1. Push and hold the  button for more than 3 seconds. The  LED icon starts flashing and the "Hur" (hour) parameter name is displayed in the Upper LED readout, its value is displayed in the Lower LED readout.

2. Pushing the  or  button alternates the LED readouts between the following:

- "Hur" (hour) in the Upper readout and its value in the lower readout
- "Min" (minute) in the Upper readout, its value in the Lower readout
- "dAY" (day) in the Upper readout, its value in the Lower readout

3. To adjust a value, press the  button and the value in the Lower LED will start flashing.

Change the value by pressing the  or  buttons. When correct, press .

4. To exit push  +  or wait 15 seconds without pressing any buttons.

## 1.7 TO SET THE ENERGY SAVING TIME (NIGHTTIME SETBACK)

Contact factory for detailed TempTrac instructions.

## 1.8 TO SET MODULATION PARAMETERS

Contact factory for detailed TempTrac instructions.

## 2. PROGRAMMING

### 2.1 SETPOINT DESCRIPTIONS AND PROGRAMMING










Setpoints are those temperature or operating parameters that the user can adjust.

**St 1** - This setpoint temperature should be considered the °F or °C temperature threshold to activate the burner. The setpoint corresponds directly to the temperature sensed by probe 1. In a boiler, probe 1 will be inserted into the return piping of the boiler heating loop. In a water heater, probe 1 will be inserted into the sidearm storage tank. The St 1 setpoint is programmed as an absolute temperature; for example 160°F.

**St 2** - This setpoint corresponds to the threshold for second-stage burner operation. The St 2 setpoint is programmed as the number of degrees below St 1 (setpoint 1) when the second stage will activate; for instance, - 8. The St 2 setpoint is only viable on products that have stage-fired burners.

**St 3** - This setpoint represents the temperature threshold for activation of freeze protection. The St 3 setpoint is programmed as an absolute temperature; for example 40°F. The St 3 setpoint is only viable on products that have freeze protection.

To program different set points proceed as described below:

1. Press the  button, the Upper LED readout will display the “St1” parameter name, while the Lower LED readout will show the corresponding value.
2. Use the  or  buttons to cycle the Upper LED readout through the St 1, St 2 and St 3 parameter names.
3. Press the  button to modify a parameter value. The value starts flashing in the Lower LED readout.
4. To change it, press the  or  buttons.
5. Press the  button to confirm the value and pass to the setting of next set point.
6. Repeat the operations described at point 3, 4, 5.
7. To exit, push  +  or wait 15 seconds without pressing any button.

**NOTE:** each point has a time out of 15 seconds. If no key is pushed within 15 seconds, the controller exits the set points programming procedure.

**NOTE:** the set value is stored even when the procedure is exited by the 15 second expiration.

## 2.2 HOW TO LOCK THE KEYBOARD



1. Push and hold the **UP + DOWN** keys for more than 3 seconds.
2. The “POF” message will be displayed and the keyboard is locked. At this point it is only possible to view the set point.
3. Repeat step 1 to unlock the keyboard.

## 2.3 HOT KEY PROGRAMMING (FOR FACTORY SUPPORTED FIELD REPROGRAMMING)

To upload a program from a control to a HOT KEY:



+



Insert HOT KEY into the TTL connection on the back of the control. Press and hold **UP + DOWN** keys momentarily then press the **UP** key. The “Up!” message will appear while uploading is occurring and the “End” message will appear when finished. Push any key to return to normal operation.

To download a program from a HOT KEY to a control:



Press the **ON/OFF** key to turn off the control. Insert the HOT KEY into the TTL connection on the back of the control. Press the **ON/OFF** key again and downloading will begin. The “don” message will appear while downloading is occurring and the “End” message will appear when finished. Push any key to return to normal operation.

## 3. ALARMS

Alarm messages are displayed in the upper LED readout and alternate with the default display. An alarm LED icon is also illuminated.

Message	Cause	Results of alarm condition
“P1”	Probe 1 failure	- Call for heat and burner second stage interrupted; modulation output signal will revert to low fire
“P2”	Probe 2 failure	- Freeze protection is disabled
“P3”	Probe 3 failure	- Outdoor reset disabled - Warm weather shut down disabled
“HA”	High temperature limit set point exceeded	- Buzzer sounds, operation continues
“LA”	Low- temperature alarm	- Buzzer sounds, operation continues
HP	High gas pressure/low water cut-off alarm	- Unit deenergized after time delay
LP	Low gas pressure alarm	- Unit deenergized after time delay
Mn1	Maintenance alert for call-for-heat	- Buzzer sounds, operation continues
Mn2	Maintenance alert for second stage	- Buzzer sounds, operation continues
Mn3	Maintenance alert for freeze protection	- Buzzer sounds, operation continues
“rtc”	The real time clock has lost the setting	- Energy saving functions disabled
“rtF”	Real time clock failure	- Energy saving functions disabled

### **3.1 BUZZER**

The buzzer, if present, is activated each time an alarm conditions happen

- High/low water temperature alarm
- Probe failures
- High and low gas pressure
- Low water

The buzzer is silenced by pressing any button (alarm condition still present)

### **3.2 ALARM RECOVERY**

1. Probe failure alarm automatically ends after normal operation is re-established. Check connections before replacing the probe.
2. Temperature alarms “**HA**” and “**LA**” automatically stop as soon as probe 1 senses temperatures within normal operating parameters.
3. High and low gas pressure alarms recover when pressure is normalized and any button is pressed.
4. Low water alarm recovers when water level normalizes and any button is pressed.
5. RTC alarm stops after programming the real time clock.
6. RTF alarm requires the replacement of the real time clock.

**For additional information, contact the Riverside Hydronics customer service department at 800-990-5918.**